
INSTALLATION INSTRUCTIONS




Suspended C60 steel profile system for 15 mm panels


These instructions apply to installation of C60 steel profile system for 15 mm panels.




STRUCTURAL SOFFIT



1: Mark the horizontal ceiling at the required height on all adjoining walls. Mark the lower side of the U-profile and fix it to the wall using 6 mm dowels in predrilled holes. Determine and mark the anchor points for the main profiles. Always install the first quick-hanger between the wall and the first cross connector, max. 300 mm from the wall. Distribute the remaining quick-hangers with a max. spacing of 1000 mm. Assemble ring hook and quick-fit suspension bracket to the desired length and fasten securely to the construction above before further installation. Then bend the ring hook into vertical position.





easily push the profile in the cross connector.

- 4: The quick-fit suspension bracket may be fixed to the main profile using screws, e.g. when installing the profile system on angled ceilings or in case of increased loads.
- 300 mm on both sides.3: Then click the installation profiles (C60 profiles) on the main profiles using the cross connectors. Terminate the profiles in the U-profiles.

2: Hold a main profile (C60 profile) with the

opening facing upwards and click the

bracket at every hanger point. Assemble

C-connectors. The main profile (C60 profile)

profile over the quick-fit suspension

the C60 profiles longitudinally using

must 'land' on the upper side of the


U-profile. If possible, divide the ceiling

space to allow for adjustments of min.


Note: If the lateral position of the profiles is not entirely precise, you can



COMPONENTS				
Product name	C60 profile 60×27 mm	C-connector	C-quick-fit suspension bracket	C-cross connector
Length (mm)	4000	80	100	
Quantity per pack	12 pcs.	100 pcs.	50 pcs.	100 pcs.
Product name	U-profile 28×27 mm	Ring hook		
Length (mm)	3000	120, 250, 375, 500, 750, 1000		
Quantity per pack	16 pcs.	100 pcs.		
Approx. qty. per m ²	According to measurement	1.1 pcs.		
	essure/suction impact, instal s quick-hangers – instead of		rstem using	
Product name	suspension bracket	Nonius quick-hanger	Nonius split-pin	
Length (mm)	100	Variable	-	
Quantity per pack	50 pcs.	100 pcs.	100 pcs.	
Approx. qty. per m ²	1.1 pcs.	1.1 pcs.	2.2 pcs.	
NONIUS, ASSEMBLY	INSTRUCTIONS	0 0		



1: Place the nonius quick-hanger in the quick-fit suspension bracket



2: Secure the quick-hanger with nonius split-pins



3: If necessary, fold the upper part of the quick-hanger

Troldtekt A/S Sletvej 2A DK - 8310 Tranbjerg J Tel +45 8747 8100 Fax +45 8747 8111 info@troldtekt.com www.troldtekt.com